



STEREO CASSETTE TAPE DECK

KX-58W/58CW

SERVICE MANUAL

KENWOOD

©1989-4 PRINTED IN JAPAN
B51-3792-00(T)2722



*Refer to Parts List on page 35.
Photo is KX-58CW.


KX-58W/58CW

CONTENTS

ACCESSRIES.....	2	ADJUSTMENT/REGLAGES/ABGLEICH.....	22
CONTROLS & INDICATORS.....	3	VOLTAGE TABLES.....	22
DISASSEMBLY FOR REPAAIR.....	4	P.C. BOARD.....	23
BLOCK & LEVEL DIAGRAM.....	5	SCHEMATIC DIAGRAM.....	29
CIRCUT DESCRIPTION.....	6	EXPLODED VIEW (MECHANISM).....	33
MECHANISM DESCRIPTION.....	12	EXPLODED VIEW (UNIT).....	34
ADJUSTMENT.....	19	PARTS LIST.....	35
REGLAGES.....	20	SPECIFICATIONS.....	Back cover
ABGLEICH.....	21		



ACCESSORIES

Accessories
Audio cord 2



KX-58W/58CW

CONTROLS & INDICATORS




KX-58W/58CW


DISASSEMBLY FOR REPAIR

*Take out the case beforehand.

1. Remove the three screws ❶ and undo the three catches ❷, then detach the dressing panel.
2. Press the EJECT button, then detach the cassette lid ❸ from the cassette holder.
3. Detach the two VR knobs ❹.
4. Remove the two screws ❺ and undo the two catches ❻, then put out the sub panel towards you.




5. Disengage the tape counter belt ❷.
6. In the EJECT mode, remove the eight screws ❸ installing the mechanism, then take out the mechanism in the direction of arrow ❹.
7. Undo the five catches, then detach the switch board ❺.



KX-58W/58CW

BLOCK & LEVEL DIAGRAM



KX-58W/58CW

CIRCUIT DESCRIPTION

FUNCTION OF COMPONENTS

Recording/Playback unit (X28-1980-10-11)

Ref. No.	Components	Use/Functions	Operation/Condition/Compatibility
IC1	LA3246	Playback EQ IC	
IC2	μ PC1330HA	Head SW IC (Deck B)	Controlled by pin 1 of IC3. Pin 4 becomes 5 V in recording and 0 V in playback.
IC3	LM6416F-2227	Microprocessor	
IC4	HA12136	Dolby B NR IC	KX-58W only.
IC5	μ PC7818HF	+ 18 V AVR	
IC6	M51951ASL	Reset IC	
IC7	M5218P-A NJM4565D	REC EQ amplifier	NF constant is determined by IC8 and IC9 to obtain the recording equalizer property.
IC8,9	BA6251	EQ selection	Pins 1-7 of IC8 (IC9) serve to control the respective equalizer devices.
IC10	TD62554S	REC EQ selector	Controlled by Q29, Q16 and Q17 to control IC8 and IC9.
IC11	AN6888	Meter IC	5-point display $\times 2 \dots -10, -6, 0, +3, +6$ dB
IC12	M5218P-A NJM4565D-D	MPX buffer	
Q1,2	2SC1740S (Q,R) 2SC945(A) (Q,P)	Playback EQ output SW (Deck B)	Controlled by Q15. ON when deck B is played and OFF when deck A is played.
Q3,4	2SC1740S (Q,R) 2SC945(A) (Q,P)	Playback EQ output SW (Deck A)	Controlled by Q15. ON when deck A is played and OFF when deck B is played.
Q5,6	2SC1740S (Q,R) 2SC945(A) (Q,P)	Playback high-frequency compensation SW (Deck A)	Controlled by Q16. Normally ON. OFF only in high-speed dubbing to decrease playback high-frequency compensation amount.
Q7,8	2SC1740S (Q,R) 2SC945(A) (Q,P)	REC muting	Controlled by Q27. ON in other than recording to mute the recording system signal.
Q9,10	2SC2878(B)	Line muting	Controlled by Q28. ON in other than playback to mute the line system signal.
Q11,12	2SC1845 (F,E)	Headphone amplifier	
Q13,14	2SC1740S (Q,R) 2SC945(A) (Q,P)	Playback EQ 120 μ /70 μ SW	Controlled by Q15. Q13 turns ON when deck A is played and Q14 turns ON when deck B is played.
Q15	2SC1740S (Q,R) 2SC945(A) (Q,P)	Playback EQ 120 μ /70 μ inverter	Controlled by pin 9 of IC3. ON when deck A is played and OFF when deck B is played.
Q16	2SC1740S (Q,R) 2SC945(A) (Q,P)	Playback EQ inverter	ON only in high-speed dubbing. Otherwise OFF.
Q17	2SC1740S (Q,R) 2SC945(A) (Q,P)	EQ speed inverter	Controlled by Q16. OFF in normal dubbing and ON in high-speed dubbing.
Q18	2SC2003 (L,K)	Dolby IC 14 V AVR control transistor	Converts signal system 18 V into Dolby 14 V.
Q19	2SD863 (E,F)	Bias OSC	Oscillates at 105 kHz.
Q20	2SC3246	Bias current METAL SW	ON in recording on metal tape
Q21	2SC3246	Bias current CrO ₂ SW	ON in recording on CrO ₂ or metal tape
Q22	2SC3246	Bias SW	ON in recording to turn ON the bias oscillation.
Q23	2SC1740S (Q,R) 2SC945(A) (Q,P)	Bias SW	ON soon at power ON
Q24	2SC733(A) (Q,P) 2SC933SC (Q,R)	A mechanism speed control	ON in high-speed operation

KX-58W/58CW

CIRCUIT DESCRIPTION

Ref. No.	Components	Use/Functions	Operation/Condition/Compatibility
Q25	2SA733(A) (Q,P) 2SA933S(Q,R)	REC mute SW	Controlled by pin 3 of IC3. ON in other than recording.
Q26	2SA733(A) (Q,P) 2SA933S(Q,R)	Line mute SW	Controlled by pin 4 of IC3. ON in other than playback.
Q27	2SA733(A) (Q,P) 2SA933S(Q,R)	REC mute SW	Controlled by Q25. ON in other than recording.
Q28	2SA733(A) (Q,P) 2SA933S(Q,R)	Line mute SW	Controlled by Q26. ON in other than playback.
Q29	2SC1740S(Q,R) 2SC945(A) (Q,P)	Tape selector SW	ON with metal tape loaded on deck B
Q30	2SC3246	B motor SW	Controlled by pin 27 of IC3. In case of relay play, OFF until the end of the tape on deck A is reached, and ON when it is reached.
Q31	2SA733(A) (Q,P) 2SA933S(Q,R)	B motor control	ON in high-speed operation
Q32	2SD863(E,F)	Microprocessor 5 V AVR	Converts 12 V for mechanism to 5 V for microprocessor.
Q33	2SD822(Q,P,E)	Mechanism 12 V AVR	Converts to 12 V for mechanism the DC obtained by halfwave rectification of AC IN.

Electric circuit module (W02-0693-05)

Ref. No.	Components	Use/Function	Operation/Condition/Compatibility
IC1	HA12088ANT	DOLBY B/C noise reduction	KX-58CW only.

KX-58W/58CW

CIRCUIT DESCRIPTION

MICROPROCESSOR LM6416F-2227

1. Operational specification

The KX-58W/58CW is a mechanism logic double deck using two mechanisms made by GIKEN. Its circuit control is performed by a microprocessor by use of inputs from mechanism attached switches and tact switches.

1-1 Functions


(1) Features

- One way × 2, double cassette
Deck A: playback only
Deck B: recording and playback
- Dubbing
Deck A to B: normal speed dubbing
Deck A to B: high speed dubbing

- Relay operation
Relay playback (only once) from deck A to B
- Timer operation
Timer playback: decks A and B either possible
Timer recording: deck B only

(2) Microprocessor controlled subjects

- Selector circuits such as of recording/playback, deck A/B, etc.
- Dolby IC
- Bias oscillation circuit
- LED indication



1-2 Pin Functions

Pin No.	Pin name	I/O	Designation	Description
1	PD0	O	BRP	B REC/PLAY selector H: REC L: PLAY
2	PD1	O	BIAS	B BIAS control H: OFF L: ON
3	PD2	O	RMUT	B REC MUTE control H: ON L: OFF
4	PD3	O	LMUT	LINE MUTE control H: ON L: OFF
5	EXtal	—	—	Oscillator
6	Xtal	—	—	Oscillator
7	INT	I	TEST	Test mode setting H: Normal L: Test
8	RES	I	RESET	RESET input H: Normal L: Reset
9	PE0	O	AHI	A/B select H: A L: B
10	PE1	O	DON	Dolby ON/OFF H: ON L: OFF
11	PE2	O	CHI	Dolby B/C H: C L: B
12	PE3	O	DRP	Dolby REC/PLAY H: REC L: PLAY
13	TEST	—	—	Connected to GND (LSI test pin)
14	Vss	—	—	Connected to GND

KX-58W/58CW

CIRCUIT DESCRIPTION

Pin No.	Pin name	I/O	Designation	Description
15	PF ₀	O	$\overline{\text{LREC}}$	REC LED H: OFF L: ON
16	PF ₁	O	$\overline{\text{LRLY}}$	Relay LED H: OFF L: ON
17	PF ₂	O	$\overline{\text{LHDB}}$	high speed dubbing LED H: OFF L: ON
18	PF ₃	O	$\overline{\text{LDUB}}$	Normal speed dubbing LED H: OFF L: ON
19	PG ₀	O	HISP	Motor speed, EQ speed select H: High L: Normal
20	V _{DD}	—	—	Connected to +5 V
21	PA ₀	I	$\overline{\text{KR0}}$	Key input H: without input L: with input
22	PA ₁	I	KR1	
23	PA ₂	I	KR2	
24	PA ₃	I	KR3	
25	PC ₀	O	$\overline{\text{KS0}}$	Key scan output H: OFF L: ON
26	PC ₁	O	KSI	
27	PC ₂	O	BCPM	B motor ON/OFF H: ON L: OFF
28	PC ₃	O	—	N.C. (OPEN)

1-3 Keys

This unit turns ON/OFF by the mechanism operation because of using mechanism logics. Its circuit control is performed with inputs of leaf switches.

Name	Operation
PLAY SW (A mechanism) ON when head of A mechanism ascends.	At ON Decks A/B: A selected Line mute turns ON and 0.5 sec later, OFF. Ignored when deck B is in recording except for dubbing. At OFF Decks A/B: B selected Line mute turns ON and, in case of during play of deck B, OFF 0.5 sec later. Ignored when deck B is in recording except for dubbing. B main motor ON.
PLAY SW (B mechanism) ON when head of B mechanism ascends.	(1) Normally At ON Decks A/B: B selected Line mute turns ON, and 0.5 sec later, OFF. Ignored when deck A is in play. At OFF Decks A/B: A selected Line mute ON. Ignored when deck A is in play. (2) For recording (not dubbing) At ON Line mute and recording mute turn ON, and 0.5 sec later, OFF. At OFF Line mute and recording muter ON. Bias OFF. (3) For dubbing At ON Line mute and recording mute turn ON and, when deck A is in play, OFF 0.5 sec later. At OFF Recording mute ON. Line mute ON unless deck A is in play. Bias OFF.

KX-58W/58CW

CIRCUIT DESCRIPTION

Name	Operation
REC SW (B mechanism) ON when REC key is pressed (with cassette hub)	(1) Normally At ON REC/PLAY: REC selected, Decks A/B: B selected Bias ON and REC LED ON. Ignored when deck A is in play. At OFF REC/PLAY: PLAY selected, Decks A/B: A selected REC LED OFF. Ignored unless REC is engaged. (2) For dubbing At ON REC/PLAY: REC selected, Decks A/B: A selected Bias ON and REC LED ON At OFF REC/PLAY: PLAY selected. REC LED OFF.
Dubbing key	Effective only when PLAY SW and REC SW are both OFF. Dubbing LED ON. High speed dubbing LED and relay LED OFF.
High speed dubbing key	Effective only when PLAY SW and REC SW are both OFF. High speed dubbing LED ON. Dubbing LED and relay LED OFF.
Relay key	Effective only when PLAY SW and REC SW are both OFF. Relay LED ON and B motor OFF. High speed dubbing LED and dubbing LED OFF

1-4 Operation

Name	Key handling	Operation
Dubbing (including High-speed mode)	Press the dubbing key.	Dubbing LED ON
	Let deck A play and set PLAY SW to ON.	Decks A/B: A selected Line mute OFF 0.5 sec later.
	Press the REC key of deck B, and set the REC SW and PLAY SW to ON.	REC/PLAY: REC selected. Dolby OFF. Bias ON. Speed is high for high-speed mode. Line mute and recording mute turn ON 0.5 sec later. Dubbing starts.
Relay play	Press the relay key.	Relay LED ON and B mechanism motor OFF.
	Let deck A play and set PLAY SW to ON.	Decks A/B: A selected. Line mute OFF 0.5 sec later. B mechanism motor OFF.
	Press the PLAY key of deck B.	Although the PLAY key of deck B is locked, since the motor is OFF, the head does not ascend and the PLAY SW of deck B thus remains OFF.
	Deck A stops (as tape end is reached or an operation key is handled)	B mechanism motor ON and thus ON PLAY SW of deck B. Decks A/B: B selected. Line mute OFF 0.5 sec later.

CIRCUIT DESCRIPTION

1-5 Initial status

	Item	Status
Circuit	BRP	PLAY
	BIAS	OFF
	REC MUTE	ON
	LINE MUTE	ON
	Dolby R/P	PLAY
Mechanism	HISP	Normal speed
	BCPM	OFF and ON 3.5 sec later.
Display		All OFF

1-6 Test mode

A test mode is added for aiming at simplified speed adjustment.

(1) Setting method

Put in 4 PIN into contact with GND (momentarily).

(2) Contents


- When the test mode is entered, an "H" signal is output to pin HISP. Namely, the mechanism is set to the high speed mode.
- Each time the high speed dubbing key is pressed, pin HISP is inverted.

(3) Canceling method (Make pin 4 open. That pin 4 remains in contact with GND is inadvisable.)


- Press the dubbing key or the relay key.
 - Perform recording.
- Needless to say, the test mode will also be canceled by power OFF.

1-7 Timing chart

① STOP→PLAY→STOP (A)



② STOP→REC→STOP (B)



KX-58W/58CW

MECHANISM DESCRIPTION

1. Function Description of Main Parts (Fig. 1 ~ 3)

- 1-1. ASSIST GEAR (36) [for playback]: This is driven by the TRIGGER ARM (II) (26) and swings the SHIFT ARM (29).
- 1-2. SHIFT ARM (29) [for playback]: This is swung by the cam of the ASSIST GEAR (36) and moves up the HEAD BASE (89) via SPRING (72).
- 1-3. PLAY ARM (30) [for playback]: Control is made by the BOSS of the HEAD BASE (89). The TAKEUP REEL ASS'Y is operated by the PLAY GEAR (34) on the PLAY ARM (30).
- 1-4. CLUTCH ASS'Y (42) [for transmission of rotation in the Play, FF, REW mode]: This transmits the rotation from the flywheel to both left and right reels via clutch for fast-forward and rewind.
- 1-5. TRIGGER ARM (II) (26) [for playback]: This is swung by the PLAY LEVER (16) via TRIGGER ARM (I) (24), and triggers the ASSIST GEAR (36).
- 1-6. LOCK CAM LEVER (II) (23) [for ejecting]: This prevents the EJECT LEVER (22) from shifting during stop operation, and it also inhibits the auto stop operation in the stop mode.
- 1-7. LOCK CAM LEVER (I) (20) [for locking of operation lever]
- 1-8. TRIGGER ARM (27) [for auto stop]: During the auto stop operation, this is swung by the power transmitted from the flywheel via the AUTO PULLEY (38) and AUTO GEAR (33), and slides the LOCK CAM LEVER (I) (20).
- 1-9. AUTO SENSOR (21) [for auto stop]: This is swung by the T REEL ASS'Y (8) and locks the AUTO CAM (32) when the rotation stops.
- 1-10. PAUSE LOCK ARM (14) [for auto stop]: This inhibits the auto stop operation in the pause mode.
- 1-11. AUTO LOCK ARM (28) [for auto stop]: This inhibits the auto stop operation during the stop or pause mode.

2. Stop Status (Fig. 1), (Fig. 3)

- 2-1. The SHIFT ARM (29) is energized by the SPRING (77).
- 2-2. The cam of the ASSIST GEAR (36) comes contact with the edge of the SHIFT ARM (29).
- 2-3. The TRIGGER ARM (II) (26) is energized by the SPRING (74).
- 2-4. The cam located on the rear of the ASSIST GEAR (36) comes contact with the boss at the edge of the TRIGGER ARM (II) (26) so that the rotation of the GEAR (36) is locked.




Fig. 1 Parts Discription (Front perspective view)

MECHANISM DESCRIPTION




Fig. 2 Discription of power transmission




Fig. 3 Parts Discription (Rear perspective view)

KX-58W/58CW

MECHANISM DESCRIPTION

3. FF (Fast-Forward) Operation (Fig. 4)

- 3-1. The CLUTCH ASS'Y (42) is stretched in the direction of ⇨ (A) by the resultant of the SPRING (71) and the FR BELT (41).
- 3-2. In the stop mode, the CLUTCH ASS'Y (42) stops at the neutral position by the lug (or protrusion) (B) of the FF LEVER (18).
- 3-3. When the FF LEVER is pressed and locked, the CLUTCH ASS'Y (42) falls down into the concave section (C) of (18).
- 3-4. The gear of the CLUTCH ASS'Y (42) is engaged with the FF GEAR (34).
- 3-5. The rotation of the FLYWHEEL (7) is transmitted to the T REEL ASS'Y (8) via the CLUTCH ASS'Y (42) and the FF GEAR (34).




Fig. 4 F.F.

4. Rewind (REW) Operation (Fig. 5)

- 4-1. The CLUTCH ASS'Y (42) is stretched in the direction of ⇨ (A) by the resultant of the SPRING (71) and the FR BELT (41). (Fig. 4)
- 4-2. In the stop mode, the CLUTCH ASS'Y (42) stops at the neutral position by the lug (or protrusion) (B) of the FF LEVER (18). (Fig. 4)
- 4-3. When the REW LEVER (17) is pressed and locked, the CLUTCH ASS'Y (42) is rotated in the direction of (B) against the force of SPRING (71) due to slope (A).
- 4-4. The gear of the CLUTCH ASS'Y (42) is engaged with the gear of the S REEL ASS'Y (9).
- 4-5. The rotation of the FLYWHEEL (7) is transmitted to the S REEL ASS'Y (9) via the CLUTCH ASS'Y (42).




Fig. 5 REW

MECHANISM DESCRIPTION

5. Play Operation (Fig. 6)

- 5-1. Press the PLAY LEVER (16) (→ ①).
- 5-2. The TRIGGER ARM (I) (24) which is fixed on the PLAY LEVER (16) with the screw is also moved in the direction of → ② .
- 5-3. The notch (A) of the TRIGGER ARM (I) (24) comes in contact with the TRIGGER ARM (II) (26). (→ ② .) At the same time, the notch (B) of the TRIGGER ARM (I) (24) comes in touch with the notch (D) of the FF and REW LEVERS (18),(17). (→ ③ .)
- 5-4. The TRIGGER ARM (I) (24) swings in the direction of → ② using (B), (D) as supporting points and (A), (C) as application points.
- 5-5. The TRIGGER ARM (II) (26) is swung in the direction of → ④ by notch (A) of the TRIGGER ARM (I) (24).
- 5-6. The edge (E) of the TRIGGER ARM (II) (26) is unlocked from the section (F) of the ASSIST GEAR (36).




Fig. 6 Play (Unlock ASSIST GEAR)

- 5-7. Since the cam (A) of the ASSIST GEAR (36) is pushed by the protrusion (B) of the SHIFT ARM (29), the ASSIST GEAR (36) is rotated in the direction of → ⑤ .
- 5-8. When rotated a bit, the gear section of the ASSIST GEAR (36) is engaged with the gear of the FLYWHEEL (7) and then it is continued.
- 5-9. By the cam (A) of the ASSIST GEAR (36), the SHIFT ARM (29) is lifted against the SPRING (77), then the hook (C) on the edge of it is swung in the direction of → ⑥ .




Fig. 7 Play (Rotate ASSIST GEAR)

KX-58W/58CW

MECHANISM DESCRIPTION

- 5-10. The HEAD BASE (89) is slid on the surface of the chassis. The hook of the HEAD BASE (89) and that of the SHIFT ARM (29) are connected with the SPRING (72).
- 5-11. When the SHIFT ARM (29) is lifted, the HEAD BASE (89) is also moved up and comes in contact with the notch (A), so that the unit (cassette deck) is entered the play mode.
- 5-12. In the play mode, due to the rise of the HEAD BASE (89), the PLAY ARM (30) is swung in the direction of ➡ 8 (by the SPRING (76)) and further pushed up by the BOSS (B) of the HEAD BASE (89).
- 5-13. When the HEAD BASE (89) reaches the play position, the PLAY GEAR (34) is engaged with the CLUTCH ASS'Y (42) and the T REEL ASS'Y (8) to transmit the rotation.




Fig. 8 Play (move up HEAD BASE)

- 5-14. The ASSIST GEAR (36) still rotates even after the HEAD BASE (89) stops and stops when the boss (E) of the TRIGGER ARM (II) (26) comes in contact with the stopper (A) of the ASSIST GEAR (36). (See Fig. 9.)
- 5-15. During the PLAY LEVER (16) is locked, the TRIGGER ARM (II) (26) is held at the position shown in the figure (Fig. 9) by the TRIGGER ARM (I) (24). (See Fig. 6.)




Fig. 9 Play (Hold play mode)

- 5-16. When the PLAY LEVER (16) is released, the TRIGGER ARM (I) (24) becomes free and the TRIGGER ARM (II) (26) is swung by the SPRING (74), and the ASSIST GEAR (36) is also unlocked. (See Fig. 9, Fig. 10.)
- 5-17. The ASSIST GEAR (36) is rotated in the direction of ➡ 5 by the pressure of the SHIFT ARM (29), and stops when the boss (E) at the edge of the TRIGGER ARM (II) (26) comes in contact with the (F) portion of the cam. (See Fig. 10.)




Fig. 10 Play (Release play mode)

MECHANISM DESCRIPTION

6. Auto Stop Operation (See Fig. 11)

- 6-1. The AUTO CAM (32) is rotated by the FLYWHEEL (7) via AUTO PULLEY (38) and AUTO GEAR (33) in the direction of ➡ ①.
- 6-2. The AUTO SENSOR LEVER (21) comes contact with the bottom of the T REEL ASS'Y (8) through the REEL WASHER (109), SPRING (66) and the T REEL SLIDER (108).
- 6-3. In the play mode, the boss (A) at the edge of the AUTO SENSOR LEVER (21) is swung in the direction of ➡ ② by the rotation of the T REEL ASS'Y (8).
- 6-4. Since the boss (A) of the AUTO SENSOR LEVER (21) moves around the inner edge of the AUTO CAM (32), it is not engaged with the protrusion (B).

- 6-5. When the T REEL ASS'Y (8) stops rotating, the boss (A) of the AUTO SENSOR LEVER (21) is moved to the center of the AUTO CAM (32) by the bank section (C) of the AUTO CAM (32) and is engaged with the protrusion (B).
- 6-6. The BOSS A of the AUTO SENSOR LEVER (21) is locked with the PROTRUSION B of the AUTO CAM (32). In this situation, the AUTO PULLEY (38) continues rotation in the direction of ➡ ③ so that the AUTO CAM (32) is moved in the direction of ➡ ④ with the point D of the AUTO GEAR (33) as the point of support.
- 6-7. The end of the AUTO ARM (27) is moved in the direction of ➡ ⑤ and moves the LOCK CAM LEVER (20) to release it. (See Fig. 12.)




Fig. 11 Auto stop (Play – Auto Stop)

- 6-8. In the stop mode, the end section (A) of the AUTO LOCK ARM (28) comes contact with the notch of the LOCK CAM LEVER (II) (23).
- 6-9. The boss (B) of the AUTO SENSOR LEVER (21) is pushed in the direction of ➡ ① by the SPRING (75) installed on the AUTO LOCK ARM (28).
- 6-10. Since the boss of the AUTO SENSOR LEVER (21) comes contact with the inner edge of the AUTO CAM (32) in the same way as when the T REEL ASS'Y (8) is rotated, the auto stop operation does not function.
- 6-11. In the pause mode, the PAUSE LOCK ARM (14) is swung by pressing with the PAUSE LEVER (11), and the other end of it make the AUTO SENSOR LEVER (21) swing in the direction of ➡ ①.
- 6-12. In the same way as the stop mode, the auto stop operation does not function.




Fig. 12 Auto stop (During STOP & PAUSE)

KX-58W/58CW

MECHANISM DESCRIPTION

7. Rec Operation (See Fig. 13)

- 7-1. The REC SENSOR ARM (15) is swung in the direction of ➡ ① (when the recordable cassette is loaded).
- 7-2. Press the REC LEVER (10) in the direction of ➡ ②. By this operation, the REC switch (S3) is turned ON.
- 7-3. At this time, the PLAY LEVER (16) is pushed by the shoulder of the REC LEVER (10), so, the unit enters the play mode from the view point of mechanism.




Fig. 13 Rec Operation

8. Pause Operation (See Fig. 14)

- 8-1. When the PAUSE LEVER (11) is pressed (in the direction of ➡ ①), notches A and B press the ends of the PINCH ROLLER ASS'Y (37) and the PLAY ARM ASS'Y (30) to swing them respectively (in the direction of ➡ ②, ③).
- 8-2. The PINCH ROLLER ASS'Y (30) is released from the CAPSTAN (7) and the PLAY GEAR (34) is released from the CLUTCH ASS'Y (42) so that the unit enters the pause mode.




Fig. 14 Pause Operation

KX-58W/58CW

ADJUSTMENT

No.	ITEM	INPUT SETTINGS	OUTPUT SETTINGS	CASSETTE TAPE DECK SETTINGS	ALIGNMENT POINTS	ALIGN FOR	FIG.
CASSETTE DECK SECTION TAPE: NORMAL, DOLBY: OFF, INPUT: LINE							0dBs=0.775V
I REC/PLAY HEAD							
[1]	DEMAGNETIZATION	-	-	POWER: OFF Remove the cassette door.	REC/PLAY head	Demagnetize the REC/PLAY head with a head demagnetizer.	
[2]	CLEANING	-	-	PLAY	REC/PLAY head erase head, capstan, pinch roller.	Clean the REC/PLAY head erase head, capstan and pinch roller using a cotton swab slightly damped with alcohol.	
[3]	AZIMUTH	MTT-114, TCC-153 10kHz, -10dB	(B)	PLAY	Azimuth adjustment screw	Maximum output.	
II PC BOARD (X28-198X-XX)							
<1>	TAPE SPEED (HI SPEED)	MTT-111, TCC-110 3kHz -4dB	(B)	* The Test mode is initiated when TP4 (TEST) is connected momentarily to the GND. PLAY	DECK A: VR 9 DECK B: VR11	Adjust the tape speed so that a 6kHz signal is produced at the center of the tape.	(a)
<2>	TAPE SPEED (NORMAL)	MTT-111, TCC-110 3kHz -4dB	(B)	* In the Test mode condition, press the HIGH DUBBING Key. PLAY	DECK A: VR10 DECK B: VR12	Adjust the tape speed so that a 3kHz signal is produced at the center of the tape.	(b)
<3>	PLAYBACK LEVEL	MTT-150 400Hz(200nWb)	(B)	PLAY	DECK A: VR3(L) VR4(R) DECK B: VR1(L) VR2(R)	Output level: -6.0dBs	(c)
		MTT-256 315Hz(160nWb)				Output level: -9.0dBs	
		MTT-256U, TCC-160 315Hz(220nWb)				Output level: -5.0dBs	
<4>	BIAS CURRENT	(A) 1kHz, -30dBs 10kHz, -30dBs	(B)	Adjust REC LEVEL so that the REC monitor output becomes -29dBs at 1kHz, then record and reproduce signal of 1kHz and 10kHz in alternation.	VR5 (L) VR6 (R)	Record 1kHz and 10kHz in alternation and adjust the variable resistors which control the bias current so that the same playback level is obtained.	(d)
<5>	RECORD LEVEL	(A) 1kHz, -10dBs	(B)	Record and reproduce a 1kHz signal under the conditions set in <4>.	VR7 (L) VR8 (R)	Adjust the variable resistors so that a playback level of -9dBs is obtained.	(e)

* The tape speed in the Test mode is switched alternately to NORMAL/HIGH SPEED by means of the NORMAL DUBBING key.
To cancel, press the NORMAL DUBBING key or RELAY key.

REGLAGES

N°	ITEM	REGLAGE DE L'ENTREE	REGLAGE DE LA SORTIE	REGLAGE DU MAGNETO -PHONE A CASSETTE	POINTS DE L'ALIGNEMENT	ALIGNER POUR	FIG.
SECTION DU MAGNETOPHONE TAPE: NORMAL, DOLBY: OFF, ENTREE: LINE							0dBs=0,775V
I TETE D'ENREGISTREMENT/LECTURE							
[1]	DEMAGNETISATION	-	-	POWER: OFF Eloigner la porte.	Tête D'ENREGISTREMENT/ LECTURE	Demagnétiser la tête D'ENREGISTREMENT/LECTURE avec un démagnétiseur de tête.	
[2]	NETTOYAGE	-	-	PLAY	Tête D'ENREGISTREMENT/ LECTURE tête d'effacement, cabestan, galetpresseur.	Nettoyer la tête D'ENREGISTREMENT/LECTURE la tête d'effacement, le cabestan et le galetpresseur avec un coton-tige légèrement imbibé d'alcool.	
[3]	AZIMUT	MTT-114, TCC-153 10kHz. -10dB	(B)	PLAY	Vis d'azimut	Sortie maximer.	
II PLAQUE IMPRIMEE (X28-198X-XX)							
<1>	VITESSE DE DEFILEMENT (HI SPEED)	MTT-111, TCC-110 3kHz -4dB	(B)	*Le mode de test est initialisé quand TP4 (test) est raccordé momentanément à GND. PLAY	DECK A: VR 9 DECK B: VR11	Régler la vitesse de bande de façon qu'un signal de 6kHz soit produit au centre de la bande.	(a)
<2>	VITESSE DE DEFILEMENT (NORMAL)	MTT-111, TCC-110 3kHz -4dB	(B)	* En condition de mode de test, pre- sser la touche HIGH DUBBING. PLAY	DECK A: VR10 DECK B: VR12	Régler la vitesse de bande de façon qu'un signal de 3kHz soit produit au centre de la bande.	(b)
<3>	NIVEAU DE LECTURE	MTT-150 400Hz(200nWb)	(B)	PLAY	DECK A: VR3(G) VR4(D) DECK B: VR1(G) VR2(D)	Niveau de sortie: -6,0dBs	(c)
		MTT-256 315Hz(160nWb)				Niveau de sortie: -9,0dBs	
		MTT-256U, TCC-160 315Hz(220nWb)				Niveau de sortie: -5,0dBs	
<4>	COURANT DE POLARISATION	(A) 1kHz. -30dBs 10kHz. -30dBs	(B)	Régler REC LEVEL de façon que la sortie de moniteur REC soit de -29dBs à 1kHz, puis en registrer et reproduire des signaux de 1kHz et 10kHz en alternance.	VR5 (G) VR6 (D)	Enregistrer un signal de 1kHz et 10kHz en alternance et ajuster les résistances variables qui commandent le courant de polarité de façon à obtenir le même niveau de lecture.	(d)
<5>	NIVEAU D'ENREGISTREMENT	(A) 1kHz. -10dBs	(B)	Enregistrer et reproduire un signal de 1kHz dans les conditions précisées en <4>.	VR7 (G) VR8 (D)	Ajuster les résistances variables de façon à obtenir un niveau de lecture de -9dBs.	(e)

* La vitesse de la bande en mode de test est alternativement commutée sur NORMAL/HIGH SPEED par la touche HIGH DUBBING.
Pour annuler, presser la touche NORMAL DUBBING ou RELAY.

ABGLEICH


NR.	GEGENSTAND	EINGANGS-EINSTELLUNG	AUSGANGS-EINSTELLUNG	KASSETTENGERÄT-EINSTELLUNG	ABGLEICH PUNKTE	ABGLEICHEN FÜR	ABB.
CASSETTEN-DECK ABTEILUNG TAPE: NORMAL, DOLBY: OFF, EINGANG: LINE							0dBs = 0,775V
I AUFNAHME/WIEDERGABE KOPF							
[1]	ENTMAGNETISIERUNG	-	-	POWER: OFF Den Kassetteneinfachdeckel oben herausziehen.	AUFNAHME/WIEDERGABE-Kopf	Entmagnetisierung von dem AUFNAHME/WIEDERGABE Kopf mit einem Tonkopf Entmagnetisierungsdrössel.	
[2]	REINIGUNG	-	-	PLAY	AUFNAHME/WIEDERGABE-Kopf Löschkopf, Tonwelle, Andruckrolle.	AUFNAHME/WIEDERGABE-Kopf, Löschkopf, Tonwelle und Andruckrolle mit einem leicht mit Alkohol befeuchteten Wattebausch reinigen.	
[3]	AZIMUT-EINSTELLUNG	MTT-114, TCC-153 10kHz, -10dB	(B)	PLAY	Azimet-Einstellschraube	Maximal Ausgang.	
II GEDRUCKTE SCHALTPLATTE (X28-198X-XX)							
<1>	BANDGESCHWINDIGKEIT (HI SPEED)	MTT-111, TCC-110 3kHz -4dB	(B)	* Der Testmodus wird aktiviert, wenn TP4 (TEST) kurzzeitig an GND angeschlossen wird. PLAY	DECK A: VR 9 DECK B: VR11	Die Bandgeschwindigkeit so justieren, daß ein 6kHz Signal auf der Mitte des Bands erzeugt wird.	(a)
<2>	BANDGESCHWINDIGKEIT (NORMAL)	MTT-111, TCC-110 3kHz -4dB	(B)	* Im Testmodus-zustand die HIGH DUBBING-Taste drücken. PLAY	DECK A: VR10 DECK B: VR12	Die Bandgeschwindigkeit so justieren, daß ein 3kHz Signal auf der Mitte des Bands erzeugt wird.	(b)
<3>	WIEDERGABE-PEGEL	MTT-150 400kHz(200nWb)	(B)	PLAY	DECK A: VR3(L) VR4(R)	Ausgangspegel: -6,0dBs	(c)
		MTT-256 315kHz(160nWb)			DECK B: VR1(L) VR2(R)	Ausgangspegel: -9,0dBs	
		MTT-256U, TCC-160 315kHz(220nWb)				Ausgangspegel: -5,0dBs	
<4>	LEERLAUFSTROM	(A) 1kHz, -30dBs 10kHz, -30dBs	(B)	REC LEVEL so justieren, daß der REC Monitorausgang -29dBs bei 1kHz wird, und danach abwechselnd Signale von 1kHz und 10kHz aufnehmen und wiedergeben.	VR5 (L) VR6 (R)	Signale von 1kHz und 10kHz abwechselnd aufnehmen und die Regelwiderstände, die den Vormagnetisierungsstrom regeln, so justieren, daß der gleiche Wiedergabepegel erzielt wird.	(d)
<5>	AUFNAHMEPEGEL	(A) 1kHz, -10dBs	(B)	Ein 1kHz Signal unter den in Punkt <4> beschriebenen Bedingungen aufnehmen und reproduzieren.	VR7 (L) VR8 (R)	Die Regelwiderstände so justieren, daß ein wiedergabepegel von -9dBs erzielt wird.	(e)

* Die Bandgeschwindigkeit im Testmodus wird mit der HIGH DUBBING-Taste abwechselnd zwischen NORMAL und HIGH SPEED umgeschaltet.
Zum Aufheben die NORMAL DUBBING-Taste oder die RELAY-Taste drücken.

KX-58W/58CW

ADJUSTMENT/REGLAGES/ABGLEICH

SYSTEM CONNECTIONS



VOLTAGE TABLES

RECORDING/PLAYBACK UNIT (X28-1098-1X)

IC1	
1~5	—
6	NOR: 0V HI: 5.2V
7	—
8	NC
9, 10	—
11	8.3V
12	8.3V
13	NC
14	—
15	NOR: 0.5V CrO ₂ /MET: 4.9V
16~29	—

IC2	
1~3	—
4	REC: 12.1V PLAY: 0.1V
5	—
6	10.3V
7~9	—

IC3	
1	REC: 12.1V PLAY: 0.1V
2~11	—
12	P: 0.1V REC: 8.7V
13~19	—
20	5.0V
21~28	—

IC4	
1	—
2	13.5V
3	—
4	REE: 6.5V
5	OFF: 8.1V B: 6.1V C: 9.0V
6~11	—
12	P: 0.1V REC: 8.7V
13~16	—

IC5	
1	32.6V
2	—
3	18.1V

IC6	
1	5.0V
2	—
3	—

IC7	
1	6.4V
2	6.4V
3	5.7V
4	—
5	5.7V
6	6.4V
7	6.4V
8	12.7V

IC8	
1~5	—
6	HI-DUB: 10.5V
7	HI-DUB: 10.5V
8~16	—

IC9	
1	HI-DUB: 10.5V
2	HI-DUB: 10.5V

IC10	
1	HI-DUB: 10.5V
2	HI-DUB: 10.5V
3~9	—

IC11	
1~8	—
9	12.5V
10	2.7V
11~17	—
18	2.1V

IC12	
1	9.1V
2	9.1V
3	7.9V
4	—
5	7.9V
6	9.0V
7	9.1V
8	18.1V

Q1	
E	—
C	—
B	ON: 0.7V

Q2	
E	—
C	—
B	ON: 0.7V

Q3	E	—
	C	—
	B	ON 0.7V

Q4	E	—
	C	—
	B	ON: 0.7V

Q5, 6, 7, 8, 9, 10	
E	—
C	—
B	—

Q11	
E	12.9V
C	18.1V
B	13.2V

Q12	
E	—
C	18.1V
B	—

Q13, 14	
E	6.3V
C	—
B	—

Q15	
E	—
C	—
B	ON: 0.7V

Q16	
E	—
C	—

Q17	E	—
	C	HI-DUB: 10.5V

Q18	
E	13.5V
C	18.1V
B	14.1V

Q19	
E	—
C	—
B	—

Q20	
E	—
C	NOR: 9.4V CrO ₂ : 5.6V MET: 0.4V
B	—

Q21 ~ 24	
E	—
C	—
B	—

Q25, 26	
E	5.0V
C	—
B	—

Q27, 28	
E	3.7V
C	NOR: 2.7V MUTE ON: 0V

Q29	
E	—
C	—

Q30	
E	—
C	12.6V
B	—

Q31	
E	—
C	—
B	—

Q32	
E	5.0V
C	12.6V
B	5.5V

ELECTRIC CIRCUIT MODULE (W02-0693-05)

IC1	
1-3	-
4	REF: 6.8V
5	OFF: 8.1V B: 6.1V C: 9.0V
6-37	-
38	P: 0.1V REC: 8.7V
39-41	-
42	13.5V

PC BOARD (Component side view)

(X28-1980-11): KX-58CW
RECORDING/PLAYBACK UNIT (X28-1980-10): KX-58W

AC120V 60Hz

X28 D/5

P.T.

X28 E/5

X28 C/5

POWER

POWER

HEADPHONE

HEADPHONE

A MECHA ASS'Y
D40-0861-05

REC BALANCE

REC LEVEL

METER X28 B/5

DOLBY

S 4

OFF

B

C

W1

W2

S 3

NOR

DUB

S 2

H1

DUB

D1

D2

D3

D4

D5

D6

D7

D8

D9

D10

D11

D12

D13

D14

D15

D16

D17

D18

D19

D20

D21

D22

D23

D24

D25

D26

D27

D28

D29

D30

D31

D32

D33

D34

D35

D36

D37

D38

D39

D40

D41

D42

D43

D44

D45

D46

D47

D48

D49

D50

D51

D52

D53

D54

D55

D56

D57

D58

D59

D60

D61

D62

D63

D64

D65

D66

D67

D68

D69

D70

D71

D72

D73

D74

D75

D76

D77

D78

D79

D80

D81

D82

D83

D84

D85

D86

D87

D88

D89

D90

D91

D92

D93

D94

D95

D96

D97

D98

D99

D100

D101

D102

D103

D104

D105

D106

D107

D108

D109

D110

D111

D112

D113

D114

D115

D116

D117

D118

D119

D120

D121

D122

D123

D124

D125

D126

D127

D128

D129

D130

D131

D132

D133

D134

D135

D136

D137

D138

D139

D140

D141

D142

D143

D144

D145

D146

D147

D148

D149

D150

D151

D152

D153

D154

D155

D156

D157

D158

D159

D160

D161

D162

D163

D164

D165

D166

D167

D168

D169

D170

D171

D172

D173

D174

D175

D176

D177

D178

D179

D180

D181

D182

D183

D184

D185

D186

D187

D188

D189

D190

D191

D192

D193

D194

D195

D196

D197

D198

D199

D200

D201

D202

D203

D204

D205

D206

D207

D208

D209

D210

D211

D212

D213

D214

D215

D216

D217

D218

D219

D220

D221

D222

D223

D224

D225

D226

D227

D228

D229

D230

D231

D232

D233

D234

D235

D236

D237

D238

D239

D240

D241

D242

D243

D244

D245

D246

D247

D248

D249

D250

D251

D252

D253

D254

D255

D256

D257

D258

D259

D260

D261

D262

D263

D264

D265

D266

D267



D268

D269

D270

</

(X28-1980-11): KX-58CW
 RECORDING/PLAYBACK UNIT (X28-1980-10): KX-58W




KX-58CW ONLY
 ELECTRIC CIRCUIT MODULE (W02-0693-05)

ELECTRIC CIRCUIT MODULE (W02-0693-05): KX-58CW only

Ref. No.	IC	Q	Address
1			2L

RECORDING/PLAYBACK UNIT (X28-1980-11): KX-58W (X28-1980-10): KX-58CW

Ref. No.	IC	Q	Address
1			4K
2			4K
3			4J
4			4J
5			3I
6			3I
7			2F
8			2G
9			2I
10			1I
11			2F
12			2F
13			5F
14			5F
15			5F
16			5F
17			5G
18			2J
19			4H
20			5G
21			5G
22			5G
23			5G
24			4D
25			2H
26			2H
27			2H
28			2H
29			5E
30			4D
31			4D
32			4E
33			2E
1			4J
2			4I
3			5E
4			2I
5			2D
6			4E
7			2G
8			3F
9			3F
10			4G
11			5I
12			1J




KX-58W (K)
 KX-58CW (K)

Refer to the schematic diagram for the values of resistors and capacitors.

PC BOARD (Foil side view)

RECORDING/PLAYBACK UNIT (X28-1980-11): KX-58W
(X28-1980-10): KX-58CW

Ref. No.	IC	Q	Address
1	4R		
2	4R		
3	4R		
4	4R		
5	3T		
6	3T		
7	2W		
8	2U		
9	2T		
10	1T		
11	2W		
12	2W		
13	5W		
14	5W		
15	5W		
16	5W		
17	5V		
18	2S		
19	4U		
20	5V		
21	5V		
22	5V		
23	5V		
24	4Y		
25	2T		
26	2U		
27	2T		
28	2U		
29	5X		
30	4X		
31	4Y		
32	4X		
33	2X		
1	4S		
2	4T		
3	5X		
4	2S		
5	2X		
6	4X		
7	2V		
8	3W		
9	3W		
10	4V		
11	5T		
12	1R		




KX-58CW ONLY

ELECTRIC CIRCUIT MODULE (W02-0693-05)


ELECTRIC CIRCUIT MODULE (W02-0693-05): KX-58CW only




Ref. No.	IC	Q	Address
1			2P

B MECHA ASS'Y
D40-0862-05



RECORDING/PLAYBACK UNIT (X28-1980-10): KX-58W





KX-58W (K)
KX-58CW (K)

Refer to the schematic diagram for the values of resistors and capacitors.

(X28-1980-11)(A/5) : KX-58W
(X28-1980-10)(A/5) : KX-58CW

MECHA. ASS'Y (A)
(D40-0861-05)

MECHA. ASS'Y (B)
(D40-0862-05)

IC1 LA3246
IC2 μ PC1330HA
IC3 LM6413F-2227
IC4 HA12136
IC5 μ PC7818HF
IC6 M51951ASL
IC7 NJM4565D or M5218P-A
IC8,9 BA6251
IC10 TD62554S
IC11 AN6888
IC12 NJM4565D-D
or M5218P-A

REC LINE
SIGNAL LINE
GND LINE
METER LINE
+B LINE

25A733(A)
25C1845
25C2003
25C2878
25C3246
25C945(A)
25D863

25D882

25A933S
25C1740S

μ PC1330HA

HA12136

TD62554S

LA3246

BA6251

M5218P-A
NJM4565D
NJM4565D-D










LM6416F-2227


HA12088ANT

μ PC7818HF

M51951ASL


AN6888





M51951ASL

AN6888



CAUTION: For continued safety, replace safety critical components only with manufacturer's recommended parts (refer to parts list). **⚠** Indicates safety critical components. To reduce the risk of electric shock, leakage-current or resistance measurements shall be carried out (exposed parts are acceptably insulated from the supply circuit) before the appliance is returned to the customer.

DC voltages are as measured with a high impedance voltmeter with a cassette loaded at playback mode. Values may vary slightly due to variations between individual instruments or/and units. Bias circuit DC voltages are as measured while in the record mode.

Les tensions c.c. doivent être mesurées avec un volt-mètre à haute impédance, une cassette étant insérée en mode du lecture. Les valeurs peuvent différer légèrement du fait des variations inhérentes aux appareils et aux instruments de mesure individuels. Les tensions c.c. du circuit de polarité doivent être mesurées, l'appareil étant en mode d'enregistrement.

Die angegebenen Gleichspannungswerte wurden bei eingesetzter Cassette in der Wiedergabe mit einem hochohmigen Spannungsmesser gemessen. Dabei schwanken die Meßwerte aufgrund von Unterschieden zwischen einzelnen Instrumenten oder Geräten u.U. geringfügig. Die angegebenen Gleichspannungswerte der Vormagnetisierungsschaltung wurden in der Aufnahme-Betriebsart gemessen.


KX-58W/58CW(K)

Y26-2900-10

KX-58W/58CW
KENWOOD


KX-58W/58CW

EXPLODED VIEW (MECHANISM)



KX-58W/58CW

EXPLODED VIEW (UNIT)



× New
Parts
Les an
Telle o

Ref
×

201
202
202
203
203

204
205

209
210
211
212

216

220

222

222

222

222

223

224

225

244

250

251

252

260

260

260

K

L

M

D1

201

202

202

203

203

204

205

209

210

211

212

216

220

222

222

222

222

223

224

225

244

250

251

252

260

260

260

K

L

M

D1

KX-58W/58CW

PARTS LIST

* New Parts

Parts without Parts No. are not supplied.

Les articles non mentionnés dans le Parts No. ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.

Ref. No. 参照番号	Address 位置	New Parts 新	Parts No. 部品番号	Description 部品名 / 規格	Desti- nation 仕向	Re- marks 備考
KX-58W/58CW						
201	1D	*	A01-1739-01	METALLIC CABINET		
202	2D	*	A20-5752-02	PANEL		
202	2D	*	A20-5760-02	PANEL		
203	2E	*	A22-1073-01	SUB PANEL		
203	2E	*	A22-1074-01	SUB PANEL		
204	2D	*	A53-1098-03	CASSETTE LID		
205	2E	*	A53-1099-03	CASSETTE LID		
209	1D	*	B03-2517-04	DRESSING PLATE		
210	1E, 2E	*	B07-1720-04	ESCUTCHEON		
211	2D	*	B11-0215-04	SMOKED FILTER		
212	1E	*	B35-0036-05	TAPE COUNTER		
-		*	B46-0092-03	WARRANTY CARD		
-		*	B46-0096-13	WARRANTY CARD		
-		*	B46-0121-03	WARRANTY CARD		
-		*	B46-0122-13	WARRANTY CARD		
-		*	B50-9435-00	INSTRUCTION MANUAL		
-		*	B50-9436-00	INSTRUCTION MANUAL		
-		*	B50-9437-00	INSTRUCTION MANUAL		
-		*	B50-9438-00	INSTRUCTION MANUAL		
-		*	B59-0155-04	SUB-INSTRUCTION MANUAL		
216	1E		D16-0096-04	BELT		
△ 220	1E		E03-0102-25	AC INLET		
△ 222	1F		E30-0181-05	AC POWER CORD		
△ 222	1F		E30-0459-05	AC POWER CORD		
△ 222	1E		E30-1305-15	AC POWER CORD (INLET)		
△ 222	1F		E30-1341-05	AC POWER CORD		
223	1D		E30-0615-05	AUDIO CORD		
-		*	H01-8434-04	ITEM CARTON CASE		
-		*	H01-8506-04	ITEM CARTON CASE		
-		*	H10-3786-02	POLYSTYRENE FOAMED FIXTURE		
-		*	H10-3787-02	POLYSTYRENE FOAMED FIXTURE		
-		*	H20-0554-04	PROTECTION COVER		
-			H25-0232-04	PROTECTION BAG (235X350X0.03)		
-			H25-0330-04	PROTECTION BAG		
224	2E		J02-0161-04	FOOT		
225	2F		J02-0366-15	FOOT		
244	1F		J42-0083-05	POWER CORD BUSHING		
-			J61-0307-05	WIRE BAND		
250	1D	*	K27-1965-04	KNOB (POWER)		
251	1E, 2E	*	K29-3582-03	KNOB (PAUSE, REC PLAY)		
252	2D	*	K29-3591-04	KNOB (REC BALANCE, REC LEVEL)		
△ 260	1F		L01-7811-05	POWER TRANSFORMER		
△ 260	1F		L01-7812-05	POWER TRANSFORMER		
△ 260	1F		L01-7814-05	POWER TRANSFORMER		
K	2E		N09-1515-05	TAPPING SCREW (3X8)		
L	2E, 2F		N86-2606-46	BINDING HEAD TAPTITE SCREW		
M	1D, 2F		N89-3008-45	BINDING HEAD TAPTITE SCREW		
RECORDING/PLAYBACK UNIT (X28-198X-XX) (0-10: KX-58CW, 0-11: KX-58W)						
D1	-18		B30-1223-05	LED(LN21CPH(V)-C)		

E: Scandinavia & Europe K: USA

P: Canada

U: PX(Far East, Hawaii) T: England

M: Other Areas

UE: AAFES(Europe)

X: Australia

W: KX-58W

C: KX-58CW

△ indicates safety critical components.

KX-58W/58CW

PARTS LIST

* New Parts

Parts without Parts No. are not supplied.

Les articles non mentionnés dans le Parts No. ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.

Ref. No. 参照番号	Address 位置	New Parts 新	Parts No. 部品番号	Description 部品名 / 規格	Desti- nation 仕向	Re- marks 備考
C1	.2		CK45FB1H391K	CERAMIC 390PF		
C3	.4		CK45FB1H681K	CERAMIC 680PF		
C5	.8		CK45FB1H391K	CERAMIC 390PF		
C9	.10		CE04KW1A101M	ELECTRO 100UF		
C11	.12		CF92FV1H103J	MF 0.010UF		
C13	.14		CF92FV1H183J	MF 0.018UF		
C15	.16		CE04KW1V4R7M	ELECTRO 4.7UF		
C17	.18		CC45FSL1H271J	CERAMIC 270PF		
C19	.20		CE04KW1H010M	ELECTRO 1.0UF		
C21	.22		CE04KW1V100M	ELECTRO 10UF		
C23	.24		CE04KW1HR22M	ELECTRO 0.22UF		
C25	.30		CE04KW1V4R7M	ELECTRO 4.7UF		
C31	.32		CE04KW1H010M	ELECTRO 1.0UF		
C33	.34		CE04KW1H0R1M	ELECTRO 0.1UF		
C35	.36		CE04KW1H010M	ELECTRO 1.0UF		
C37	.38		CE04KW1C330M	ELECTRO 33UF		
C39	.40		CE04KW1V4R7M	ELECTRO 4.7UF		
C41	.42		CF92FV1H152J	MF 1500PF		
C43	.44		CE04KW1HR22M	ELECTRO 0.22UF		
C45	.46		CF92FV1H822J	MF 8200PF		
C47	.48		CE04KW1H010M	ELECTRO 1.0UF		
C49	.50		CE04KW1V100M	ELECTRO 10UF		
C51	.52		CC45FSL1H221J	CERAMIC 220PF		
C53	.54		CE04KW1V100M	ELECTRO 10UF		
C55	.56		CF92FV1H472J	MF 4700PF		
C57	.58		CF92FV1H822J	MF 8200PF		
C59	.62		CF92FV1H103J	MF 0.010UF		
C63	.64		CF92FV1H392J	MF 3900PF		
C65	.66		CF92FV1H822J	MF 8200PF		
C67	.68		CF92FV1H103J	MF 0.010UF		
C69	.70		CF92FV1H682J	MF 6800PF		
C71	.72		CF92FV1H332J	MF 3300PF		
C73	.74		CK45FB1H102K	CERAMIC 1000PF		
C75	.76		CC45FSL1H221J	CERAMIC 220PF		
C77	.78		CF92FV1H103J	MF 0.010UF		
C101	.102		CE04KW1V4R7M	ELECTRO 4.7UF		
C103			CE04KW1C101M	ELECTRO 100UF		
C104	.105		CE04KW1C220M	ELECTRO 22UF		
C106			CE04KW1V100M	ELECTRO 10UF		
C107			CE04KW1C101M	ELECTRO 100UF		
C108			CE04KW1A331M	ELECTRO 330UF		
C109			CE04KW1C220M	ELECTRO 22UF		
C109			CE04KW1V4R7M	ELECTRO 4.7UF		
C110			CE04KW1V4R7M	ELECTRO 4.7UF		
C111			CE04KW1V100M	ELECTRO 10UF		
C112			C91-0773-05	POLYPRO 1000PF		
C113	.114		CE04KW1V100M	ELECTRO 10UF		
C115			CF92FV1H682J	MF 6800PF		
C116			CF92FV1H222J	MF 2200PF		
C117			CF92FV1H103J	MF 0.010UF		
C118	.119		CC45FSL1H331J	CERAMIC 330PF		
C120	.121		CE04KW1V100M	ELECTRO 10UF		
C122			CE04KW0J471M	ELECTRO 470UF		
C123			CE04KW1A101M	ELECTRO 100UF		
C124	.125		CE04KW1V100M	ELECTRO 10UF		

E: Scandinavia & Europe K: USA

P: Canada

U: PX(Far East, Hawaii) T: England

M: Other Areas

UE: AAFES(Europe)

X: Australia

W: KX-58W

C: KX-58CW

△ indicates safety critical components.

PARTS LIST

* New Parts

Parts without Parts No. are not supplied.

Les articles non mentionnés dans le Parts No. ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.

Ref. No. 参照番号	Address 位置	New Parts 新	Parts No. 部品番号	Description 部品名 / 規格	Desti- nation 仕 向	Re- marks 備考
C126 C127 C128 C129 C130			CE04KW1C330M CE04KW1E101M CF92FV1H472J CK45FF1H103Z CE04KW1V102M	ELECTR0 33UF 16WV ELECTR0 100UF 25WV MF 4700PF J CERAMIC 0.010UF Z ELECTR0 1000UF 35WV		C
C131 C132 C133, 134 C135 C136-138			CK45FF1H223Z CE04KW1H010M CE04KW1C101M CE04KW1E102M CK45FF1H103Z	CERAMIC 0.022UF Z ELECTR0 1.0UF 50WV ELECTR0 100UF 16WV ELECTR0 1000UF 25WV CERAMIC 0.010UF Z		
C139 C140 C141			CK45FF1H223Z CE04KW1C331M CE04KW1H0R1M	CERAMIC 0.022UF Z ELECTR0 330UF 16WV ELECTR0 0.1UF 50WV		
E1 E2			E13-0446-05 E11-0162-05	PHONE JACK (4P) PHONE JACK (3P)		C
L1 .2 L3 .4 L5 .6 L7 .8 L9 .10			L39-0145-05 L39-0171-05 L40-1835-29 L40-6825-29 L79-0720-05	LW OSCILLATING COIL TRAP COIL SMALL FIXED INDUCTOR(18MH,G) SMALL FIXED INDUCTOR(6.8MH,J) LC FILTER		
L11 X1			L32-0381-05 L78-0202-05	BIAS OSCILATING COIL RESONATOR (400KHZ)		
M N	2F 1F		N89-3008-45 N30-3006-46	BINDING HEAD TAPTITE SCREW PAN HEAD MACHINE SCREW		
CP1 R47 .48 R136 R138 VR1 -4			R90-0487-05 RS14KB3A561J RD14GB2E470J RD14GB2E6R8J R12-3128-05	MULTI-COMP 47KX4 J 1/6W FL-PROOF RS 560 J 1W FL-PROOF RD 47 J 1/4W FL-PROOF RD 6.8 J 1/4W TRIMMING POT. (22K)PB LEVEL		C
VR5 .6 VR7 .8 VR9 VR10 VR11			R12-5071-05 R12-3128-05 R12-1089-05 R12-3126-05 R12-1089-05	TRIMMING POT. (220K)BIAS CURR. TRIMMING POT. (22K) REC LEVEL TRIMMING POT. (4.7K)TAPE SPEED TRIMMING POT. (10K) TAPE SPEED TRIMMING POT. (4.7K)TAPE SPEED		
VR12 VR13 VR14			R12-3126-05 RD6-4079-05 RD1-5065-05	TRIMMING POT. (10K) POTENTIOMETER POTENTIOMETER		
S1 -3 S4 S5			S40-1064-05 S31-1017-05 S40-2358-05	PUSH SWITCH SLIDE SWITCH PUSH SWITCH (POWER TYPE)		
D19 -23 D19 -23 D24 D24 D25			HSS104 1SS133 HZS8.2N(B) RDB.2ES(B) HZS15N(B)	DIODE DIODE ZENER DIODE ZENER DIODE ZENER DIODE		
D25 D26 -34 D26 -34 D35 D35			RD15ES(B) HSS104 1SS133 HZS5.6N(B2) RDS.6ES(B2)	ZENER DIODE DIODE DIODE ZENER DIODE ZENER DIODE		
D36 D36			HZS13N(B2) RD13ES(B2)	ZENER DIODE ZENER DIODE		

E: Scandinavia & Europe K: USA P: Canada
U: PX(Far East, Hawaii) T: England M: Other Areas
UE: AAFES(Europe) X: Australia

W: KX-58W
C: KX-58CW

 indicates safety critical components.

PARTS LIST

* New Parts

Parts without Parts No. are not supplied.

Les articles non mentionnés dans le Parts No. ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.

Ref. No. 参照番号	Address 位置	New Parts 新	Parts No. 部品番号	Description 部品名 / 規格	Desti- nation 仕 向	Re- marks 備考
D37 D38 D39 D39 D40			S5566B KBPO2ML-6127 HZS4.7N(B) RD4.7ES(B) HSS104	DIODE DIODE ZENER DIODE ZENER DIODE DIODE		
D40 IC1 IC2 IC3 IC4		*	1SS133 LA3246 UPC1330HA LM6416F-2227 HA12136	DIODE IC(PREAMP X2) IC(2CH HEAD SWITCHING) IC(MICROPROCESSOR) IC(DOLBY B NR SYSTEM)		W
IC5 IC6 IC7 IC7 IC8 .9			UPC7818HF M51951ASL M5218P-A NJM4565D BA6251	IC(VOLTAGE REGULATOR/ +18V) IC(SYSTEM RESET) IC(OP AMP X2) IC(OP AMP X2) IC(7CH TRANSISTOR ARRAY)		
IC10 IC11 IC12 IC12 Q1 -8			TD625545 AN6888 M5218P-A NJM4565D-D 2SC1740S(Q,R)	IC(4CH TRANSISTOR ARRAY) IC(SPT LED LEVEL METER DR X2) IC(OP AMP X2) IC(OP AMP X2) TRANSISTOR		
Q1 -8 Q9 .10 Q11 .12 Q13 -17 Q13 -17			2SC945(A)(Q,P) 2SC2878(B) 2SC1845(F,E) 2SC1740S(Q,R) 2SC945(A)(Q,P)	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR		C
Q18 Q19 Q20 -22 Q23 Q23			2SC2003(L,K) 2SD863(E,F) 2SC3246 2SC1740S(Q,R) 2SC945(A)(Q,P)	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR		
Q24 -28 Q24 -28 Q29 Q29 Q30			2SA733(A)(Q,P) 2SA933S(Q,R) 2SC1740S(Q,R) 2SC945(A)(Q,P) 2SC3246	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR		
Q31 Q31 Q32 Q33			2SA733(A)(Q,P) 2SA933S(Q,R) 2SD863(E,F) 2SD882(Q,P,E)	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR		
DT1	1F		W02-0693-05	ELECTRIC CIRCUIT MODULE		C
ELECTRIC CIRCUIT MODULE (W02-0693-05) (KX-58CW ONLY)						
C1 C3 .4 C5 .6 C7 .8 C9 .10			CK45F1H103Z CE04FW1H100M CQ92M1H103J CE04FW1H010M CQ92M1H183J	CERAMIC 0.010UF Z ELECTR0 10UF 50WV MYLAR 0.010UF J ELECTR0 1.0UF 50WV MYLAR 0.018UF J		
C11 .12 C13 .14 C15 .16 C17 .18 C19 .20			CE04FW1HR68M CE04FW1H2R2M CQ92M1H183J CQ92M1H103J CQ92M1H823J	ELECTR0 0.68UF 50WV ELECTR0 2.2UF 50WV MYLAR 0.018UF J MYLAR 0.010UF J MYLAR 0.082UF J		
C21 .22 C23 .24			CE04FW1HR68M CE04FW1H2R2M	ELECTR0 0.68UF 50WV ELECTR0 2.2UF 50WV		

E: Scandinavia & Europe K: USA P: Canada
U: PX(Far East, Hawaii) T: England M: Other Areas
UE: AAFES(Europe) X: Australia

W: KX-58W
C: KX-58CW

 indicates safety critical components.

PARTS LIST

※ New Parts
Parts without Parts No. are not supplied.
Les articles non mentionnés dans le Parts No. ne sont pas fournis.
Teile ohne Parts No. werden nicht geliefert.

Ref. No. 参照番号	Address 位置	New Parts 新	Parts No. 部品番号	Description 部品名 / 規格	Desti- nation 仕向	Re- marks 備考
L1 ,2			L39-0106-05	TRAP COIL(19K)		
IC1			HA12088ANT	IC(DOLBY B/C NOISE REDUCTION)		
MECHANISM ASS'Y (D40-0861-05:A) (D40-0862-05:B)						
1	1B		A11-0231-08	SUB CHASSIS ASSY		
3	2A		A53-0753-08	CASSETTE HOLDER		
7	2C		D01-0092-08	FLYWHEEL ASSY		
8	2B		D03-0261-08	REEL DISK ASSY		
9	1B		D03-0262-08	REEL DISK		
10	1B		D10-1942-08	LEVER (REC)	B	
11	1C		D10-1943-08	LEVER ASSY (PAUSE)	B	
14	1B		D10-1946-08	ARM (PAUSE LOCK)	B	
15	1A		D10-1947-08	ARM (REC SENSOR)	B	
16	1C		D10-1948-08	LEVER (PLAY)		
17	1C		D10-1949-08	LEVER (REW)		
18	1C		D10-1950-08	LEVER (FF)		
19	1C		D10-1951-08	LEVER (STOP)		
20	1C		D10-1952-08	LEVER (LOCK CAM)		
21	1B		D10-1953-08	LEVER (AUTO SENSOR)		
22	2B		D10-1954-08	LEVER (EJECT)		
23	1C		D10-1955-08	LEVER ASSY (LOCK CAM)		
24	1C		D10-1956-08	ARM (TRIGGER)		
25	1C		D10-1957-08	ARM (INTER LOCK)		
26	1C		D10-1958-08	ARM (TRIGGER)		
27	1C		D10-1959-08	ARM (AUTO)		
28	1C		D10-1960-08	ARM (AUTO LOCK)		
29	1B		D10-1961-08	ARM (SHIFT)		
30	2B		D10-1962-08	ARM ASSY (PLAY)		
31	1C		D12-0109-08	CAM (PAUSE)	B	
32	1C		D12-0119-08	CAM (AUTO)		
33	1C		D13-0615-08	GEAR (AUTO)		
34	2B		D13-0616-08	GEAR (PLAY)		
35	1B		D13-0617-08	GEAR (FF)		
36	1B		D13-0618-08	GEAR (ASSIST)		
37	2B		D14-0188-08	PINCH ROLLER ASSY		
38	2B		D15-0264-08	PULLEY (AUTO)		
39	2C		D16-0162-08	BELT (FR)		
40	2C		D16-0161-08	BELT (AUTO)		
41	2C		D16-0160-08	BELT (DRIVE)		
42	2B		D19-0095-08	CLUTCH ASSY		
43	2A		D21-1100-08	SHAFT (BUTTON)		
44	2B		D23-0220-08	RETAINER		
45	2B		D39-0187-08	DAMPER ASSY		
52	2A	*	E31-7183-08	CONNECTING WIRE(8P)HEAD	B	
51	1A	*	E31-7184-08	CONNECTING WIRE(12P)	B	
52	2A	*	E31-7185-08	CONNECTING WIRE(3P)HEAD	A	
51	1A	*	E31-7186-08	CONNECTING WIRE(8P)	A	
57	2C		F07-0471-08	COVER (SWITCH)		
61	2A		G01-1705-08	TORSION COIL SPRING(CASET HOLD		
62	1C		G01-2055-08	COMPRESSION SPRING(PAUSE CAM)	B	
63	1C		G01-2206-08	CUSHION (MOTOR)		
64	1C		G01-2057-08	COMPRESSION SPRING(LEVER)		
65	1C		G01-2058-08	COMPRESSION SPRING(LEVER)		

E: Scandinavia & Europe K: USA P: Canada
U: PX(Far East, Hawaii) T: England M: Other Areas
UE: AAFES(Europe) X: Australia

A: Deck A Mechanism
B: Deck B Mechanism

⚠ indicates safety critical components.

PARTS LIST

※ New Parts
Parts without Parts No. are not supplied.
Les articles non mentionnés dans le Parts No. ne sont pas fournis.
Teile ohne Parts No. werden nicht geliefert.

Ref. No. 参照番号	Address 位置	New Parts 新	Parts No. 部品番号	Description 部品名 / 規格	Desti- nation 仕向	Re- marks 備考
66	1B		G01-2059-08	COMPRESSION SPRING(AUTO SENSOR		
67	1B		G01-2060-08	COMPRESSION SPRING(REEL DISK)		
68	1C		G01-2061-08	COMPRESSION SPRING(LEVER)		
69	2A		G01-2062-08	COMPRESSION SPRING(R/P HEAD)		
70	1C		G01-2063-08	TENSION SPRING (LOCK CAM)		
71	1C		G01-2064-08	TENSION SPRING (ARM)		
72	2A		G01-2065-08	TENSION SPRING (SHIFT ARM)	B	
73	2B		G01-2093-08	TENSION SPRING (EJECT)		
74	1C		G01-2067-08	TORSION COIL SPRING(TRIGER ARM		
75	1C		G01-2068-08	TORSION COIL SPRING(AL ARM)		
76	2B		G01-2069-08	TORSION COIL SPRING(PLAY ARM)		
77	1B		G01-2070-08	TORSION COIL SPRING(SHIFT ARM)		
78	2A		G01-2071-08	TORSION COIL SPRING(PR)		
79	2A		G02-0194-08	FLAT SPRING (CASET CLAMP)		
80	1B		G02-0419-08	FLAT SPRING		
82	2B		G01-2066-08	TENSION SPRING (EJECT)	A	
83	2B		G01-2401-08	COMPRESSION SPRING(FF GEAR)		
84	1C		G01-2207-08	TENSION SPRING (AUTO ARM)		
85	1A		J11-0154-08	COLLER (BUTTON)		
86	1B		J11-0097-08	WIRE CLAMPER	B	
87	1A		J19-2833-08	BRACKET (REC SW)	B	
88	2B		J19-2834-08	HOLDER (BUTTON)		
89	2A		J19-2835-08	HOLDER (HEAD)		
90	2C		J21-5046-08	MOUNTING HARDWARE(MOTOR)		
91	2B		J31-0252-08	COLLAR (BUTTON)	A	
92	1B,1C		J42-0133-08	BUSHING		
-			J61-0307-05	WIRE BAND		
103	2B		N10-2020-46	NUT (M2)		
104	2C		N19-0524-04	FLAT WASHER (/2.1)		
106	1B,2B		N19-1031-08	FLAT WASHER (/1.6)		
107	2B		N19-1036-08	FLAT WASHER (/1.6)		
108	2B		N19-1215-08	FLAT WASHER		
109	1B		N19-1080-08	FLAT WASHER (REEL)		
110	2B		N19-1081-08	FLAT WASHER (/2.1)		
112	2B		N19-1083-08	FLAT WASHER (/1.2)		
113	1B		N09-1034-08	STEPPED SCREW (MOTOR)		
114	1B		N19-1216-08	FLAT WASHER (T REEL SLIDER)		
115	2C		N19-1198-08	FLAT WASHER		
A	1A,2A		N09-1496-08	TAPTITE SCREW (/2X4)		
B	1C		N09-1507-08	STEPPED SCREW		
D	1B		N09-1675-08	TAPTITE SCREW (/2.6X5)		
E	2B		N09-1808-08	TAPTITE SCREW (/2X14)		
F	2B		N09-1809-08	TAPPING SCREW (/2X6)		
G	2A		N09-1810-08	SCREW (/2X6)		
H	2A		N35-2008-46	LEAF SWITCH (PLAY)		
J	2C		N09-2660-08	SCREW (M2.6X3)		
S1	2B		S46-1061-08	LEAF SWITCH (CR02)	B	
S2 ,3	1A		S46-1088-08	LEAF SWITCH (METAL,REC)	A	
S4	1A		S46-1098-08	LEAF SWITCH (PLAY)	B	
S4	2A		S46-1111-08	LEAF SWITCH (PLAY)		
S5	1B		S46-1099-08	LEAF SWITCH (POWER)		
124	2A		T32-0315-08	ERASE HEAD	B	
125	2A		T32-0308-05	ERASE HEAD (DUMMY)	A	
126	2A		T34-0331-08	REC/PB HEAD		
M1	2C		T42-0432-08	MOTOR ASSY		

E: Scandinavia & Europe K: USA P: Canada
U: PX(Far East, Hawaii) T: England M: Other Areas
UE: AAFES(Europe) X: Australia

A: Deck A Mechanism
B: Deck B Mechanism

⚠ indicates safety critical components.

KX-58W/58CW

KX-58W/58CW

SPECIFICATIONS

Type.....	Stereo double cassette deck with Dolby NR System
Track System	4-track, 2-channel Stereo, Recording/Playback
Recording System	AC Bias System (Bias Frequency: 105 kHz)
Erasing System	AC System
Tape Speed	4.76 cm/sec (1-7/8 ips)
Heads (Deck A)	Playback Head x 1
(Deck B)	Record and Playback Head x 1 Erase Head x 1
Motor	2 motors: Electronically Controlled DC Motor
Fast Winding Time	Approx. 110 seconds with C-60 tape
Frequency Response: (± 6 dB) — 20dB recording	
Normal Tape	20 Hz to 15,000 Hz
CrO ₂ Tape	20 Hz to 16,000 Hz
Metal Tape	20 Hz to 16,000 Hz
Signal-to-Noise Ratio:	
Dolby C Type NR ON	72 dB (KX-58CW) (Normal Tape)
Dolby B Type NR ON	64 dB (Normal Tape)
Dolby NR OFF	56 dB (Normal Tape)

Harmonic Distortion	Less than 0.9% (at 1 kHz, 0 dB, 3rd H.D. with Normal Tape)
Wow and Flutter	0.15% (WRMS), $\pm 0.3\%$ (DIN)
Input Sensitivity/ Impedance:	
LINE IN	77.5 mV/50 kohms
Output Level/Impedance:	
LINE OUT	270 mV/3.9 kohms
Headphones	0.2 mW/8 ohms (KX-58CW)

GENERAL

Power Consumption	15 W
Dimensions	W: 440 mm (17-5/16") H: 119 mm (4-11/16") D: 268 mm (10-9/16")
Weight	4.1 kg (9 lb) (KX-58CW) 4.0 kg (8.8 lb) (KX-58W)

Kenwood follows a policy of continuous advancements in development
For this reason specifications may be changed without notice
DOLBY and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation
Noise reduction circuit made under license from Dolby Laboratories Licensing Corporation.

Kenwood poursuit une politique de progrès constants en ce qui concerne le développement.
Pour cette raison, les spécifications sont sujettes à modifications sans préavis
La marque DOLBY et le double "D" sont des marques déposées des Dolby Laboratories
Le système de réduction du bruit de fond est fabriqué sous licence des Dolby Laboratories

Kenwood strebt ständige Verbesserungen in der Entwicklung an.
Daher bleiben Änderungen der technischen Daten jederzeit vorbehalten.
DOLBY und Doppel-D-Symbol sind eingetragene Warenzeichen der Dolby Laboratories.
Dolby-Rauschunterdrückung mit Lizenz der Dolby Laboratories gefertigt.

Note:

Component and circuitry are subject to modification to insure best operation under differing local conditions. This manual is based on, the U.S. (K) standard, and provides information on regional circuit modification through use of alternate schematic diagrams, and information on regional component variations through use of parts list.

KENWOOD CORPORATION

Shionogi Shibuya Building, 17-5, 2-chome Shibuya, Shibuya-ku, Tokyo 150, Japan

KENWOOD U.S.A. CORPORATION

2201 East Dominguez Street, Long Beach, CA 90810;
550 Clark Drive, Mount Olive, NJ 07828, U.S.A.

KENWOOD ELECTRONICS CANADA INC.

P.O. Box 1075 959 Gana Court, Mississauga, Ontario, Canada L4T 4C2

KENWOOD ELECTRONICS BENELUX N.V.

Mechelsesteenweg 418 B-1930 Zaventem, Belgium

KENWOOD ELECTRONICS DEUTSCHLAND GMBH

Rembrucker-Str. 15, 6056 Heusenstamm, West Germany

TRIO-KENWOOD FRANCE S.A.

Hi-Fi-VIDEO-CAR Hi-Fi
13, Boulevard Ney, 75018 Paris, France

TRIO-KENWOOD U.K. LTD.

17 Bristol Road, The Metropolitan Centre, Greenford, Middx. UB6 8UP England

KENWOOD ELECTRONICS AUSTRALIA PTY. LTD.

4E Woodcock Place, Lane Cove, N.S.W. 2066, Australia

KENWOOD & LEE ELECTRONICS, LTD.

Wang Kee Building, 4th Floor, 34-37, Connaught Road, Central, Hong Kong